

INSTALLATION INSTRUCTIONS FOR WASHIE TOILET SEAT

IMPORTANT! FOR SECURE MOUNTING, FOLLOW INSTRUCTIONS THOROUGHLY. PLEASE SCAN QR CODE FOR INSTRUCTIONAL VIDEOS.

SCAN



INCLUDED IN THIS BOX:

- WASHIE TOILET SEAT
- NUT (2), FLAT WASHER (2), LOCK WASHER (2)
- EXTENTION
- BATTERY PACK
- BATTERY CHARGING CORD
- COMPARTMENT KEY
- 3 STEP INSTRUCTION STICKER

TOOLS NEEDED:

- 13 mm - 2.5" ratchet
- For effortless installation please use the **Flexible** head 13 mm ratchet wrench.



CONTACT US AT WWW.WASHIEPRO.COM

INSTALLATION INSTRUCTIONS FOR WASHIE TOILET SEAT

IMPORTANT! FOR SECURE MOUNTING, FOLLOW INSTRUCTIONS THOROUGHLY. PLEASE SCAN QR CODE FOR INSTRUCTIONAL VIDEOS.

SCAN



INSTALLING WASHIE TOILET SEAT

- Align the extension attached to the seat. Ensure the extension is facing upwards & arrows are facing the “wall” as seen in the picture below.
- Mount seat on toilet bowl.
- Insert bolts through bolt holes.
- Add flat washer, lock washer and nut to bolt on underside of bowl.
- Secure nut using 13mm - 2.5” ratchet wrench.



INSTALLING CARTRIDGE

PLEASE SCAN QR CODE FOR INSTRUCTIONAL VIDEOS.

SCAN



- Open cartridge door using compartment door key.
- Prime the cartridge - Face the cartridge into the toilet bowl. Press down on the cartridge pump several times until foam exits the nozzle.
- Insert cartridge in seat with “THIS SIDE UP” facing upwards.
- Lock cartridge into place by turning cartridge lock to the left.
- If seat is already powered ON, seat will beep once when new cartridge is installed.



- When cartridge is low, the seat will beep once every 60 seconds.
- Each cartridge holds 2000 uses and is 100% recyclable.
- Once a cartridge is empty, remove used cartridge and recycle appropriately.

INSTALLING BATTERY

PLEASE SCAN QR CODE FOR INSTRUCTIONAL VIDEOS.

SCAN



- Open battery door using compartment door key.
- Insert battery with “THIS SIDE UP” facing upward.
- Battery will *click* when properly inserted.
- Turn device ON using ON/OFF switch, seat will beep once.
- Replace battery door and lock using compartment key.



- When the battery is low, the seat will beep twice every 60 seconds.
- Batteries can keep a charge for 60-90 days depending on restroom traffic.
- The battery will need to charge for approximately 8 hours. A green light on the charging cord will indicate that the battery is fully charged.
- Please unplug from charging cord (D) as soon as it is done charging DO NOT OVERCHARGE.
- When needed, dispose of lithium-ion battery according to local battery disposal regulations.

INSTALLING STICKERS

PLEASE SCAN QR CODE FOR INSTRUCTIONAL VIDEOS.

SCAN



- Peel and stick the instruction sticker directly above the toilet on wall.
- If you have received a QR Code Survey Sticker, please peel and place sticker on the back of stall door.
- Please do NOT stick stall sticker directly under a coat hanger where it can be blocked from view.

3-STEP INSTRUCTION STICKER



QR CODE SURVEY STICKER

